

11-1-70

COLETRONICS SERVICE, INC.
1744 Rockaway Avenue
Hewlett, L. I., N. Y. 11557

NEW TUBE RELEASES
for use with
TRC 2-1-70 DATA BOOK

TUBE	SECT	A	B	C	D	CATH	CONT	TEST
1DG3		35	2	47	4	-	3456	0
	No short test							
3DF3		35	5	20	4	-	23468	0
	No short test							
3DJ3		2	5	27	4	-	12357	0
4GS7	Tri	4	6	21	2	38	38	12
"	Pen	4	6	19	2	-	-	679
4MK8	Pen-1	4	6	22	2	1	-	237
"	Pen-2	4	6	22	2	-	-	278
5AQ4	Plate-1	2	8	6	1	-	-	4
"	Plate-2	2	8	6	1	-	-	6
5MF8								
(Key at 8)	Pen	9	8	22	2	4	12	●1230
	●Ignore glow on 1							
(Key at 5)	Tri	6	8	21	2	3	-	27
6AQ8	Tri-1	4	9	22	2	8	-	67
"	Tri-2	4	9	22	2	3	-	12
6BW3								
(Key at 0)		1	9	17	3	7	-	4
6DN3		5	9	20	2	9	27	27
6DS5		3	9	25	2	2	17	●1756
	●Ignore glow on 1							
6HL7		6	9	20	2	1	3459	●39278
	●Ignore glow on 3							
6JB5								
(Key at 2)		1	9	19	3	6	0	4580
	Must show short on 5-0							
6KS8	Tri	4	9	25	2	1	-	23
"	Pen	4	9	23	2	6	-	789
6MU8	Tri	4	9	24	2	8	-	19
"	Pen	4	9	24	2	7	-	236
6RA 6		5	9	17	3	1	27	29
	Must show short on 2-7							
	Grid short test - throw 2-7 together							
8KS8	Tri	4	10	25	2	1	-	23
"	Pen	4	10	23	2	6	-	789
8LX8	Tri	4	10	22	2	8	-	19
"	Pen	4	10	21	2	7	-	236
8MD8	Tri-1	4	10	22	2	7	-	36
"	Tri-2	4	10	22	2	-	-	28
"	Tri-3	4	10	22	2	-	-	19

TUBE	SECT	A	B	C	D	CATH	CONT	TEST
8MU8	Tri	4	11	24	2	8	-	19
"	Pen	4	11	24	2	7	-	236
9AH9								
(Key at 0)	Tri	1	11	23	2	4	56	23
(Key at 7)	Pen	1	11	21	2	1	-	250
9MN8								
(Key at 6)	Tri-1	7	11	24	2	-	-	48
(Key at 5)	Tri-2	6	11	24	2	-	-	29
(Key at 0)	Tri-3	1	11	24	2	3	-	68
9RA 6		5	11	17	3	1	27	29
Must show short on 2-7								
Grid short test - throw 2-7 together								
10AF11								
(Key at 0)	Tri-1	1	12	24	2	5	-	68
	Tri-2	1	12	25	2	7	-	34
(Key at 5)	Pen	6	12	25	2	1	-	237
10LM8	Tri	4	12	23	2	8	-	19
"	Pen	4	12	23	2	7	-	236
10LY8	Tri	4	12	22	2	1	-	23
"	Pen	4	12	20	2	6	-	789
10T10								
(Key at 6)	Pen-1	5	12	19	3	2	-	134
(Key at 2)	Pen-2	1	12	19	3	4	-	5789
10Z10								
(Key at 0)	Pen-1	0	12	26	4	8	1	4567
(Key at 6)	Pen-2	5	12	18	3	9	7	248
12AF11								
(Key at 0)	Tri-1	1	13	24	2	5	-	68
	Tri-2	1	13	25	2	7	-	34
(Key at 5)	Pen	6	13	25	2	1	-	237
12CT3		4	13	23	2	9	26	●26
●Ignore glow on 2								
12DZ7	Pen-1	2	13	5	1	8	-	456
"	Pen-2	2	13	5	1	-	-	134
12HB25*		4	13	21	2	9	123678	●12670
●Ignore glow on 1-6. Cap goes to top of tube.								
*Must use magnoval adapter.								
12HU8	Pen-1	4	13	22	2	7	-	123
"	Pen-2	4	13	22	2	-	-	689
15MF8								
(Key at 8)	Pen	9	14	22	2	4	12	●1230
●Ignore glow on 1								
(Key at 5)	Tri	9	14	21	2	3	-	27
17JF6		4	15	20	2	3	1267	●12670
●Ignore glow on 1-2-6. Cap goes to top of tube.								
17Y9	Pen-1	5	15	20	2	7	-	890
"	Pen-2	5	15	20	2	2	-	134

TUBE	SECT	A	B	C	D	CATH	CONT	TEST
19FL8	Pen	4	16	24	2	3	-	1269
"	Di-1	4	16	21	3	-	-	7
"	Di-2	4	16	21	3	-	-	8
19FX5		3	16	17	3	-	25	267
	Lever #5 must be thrown to open position							
20EW7	Tri-1	4	16	27	2	8	-	67
"	Tri-2	4	16	23	2	9	23	●123
	●Ignore glow on 2							
20LF6 (Key at 4)		3	16	21	2	6	1278	●2790
	●Ignore glow on 2. Cap goes to top of tube.							
22KV6		4	17	20	2	3	17	279
	Lever #1 must be thrown to open position							
25BB14*		4	18	20	2	38	123678	●12670
	●Ignore glow on 1-6. Cap goes to top of tube.							
	*Must use magnoval adapter							
25JZ8 (Key at 8)	Pen	9	18	23	2	4	12	●1230
	●Ignore glow on 1							
(Key at 5)	Tri	6	18	26	2	3	-	27
26HV5 (Key at 0)		1	18	20	2	4	-	27
30JZ6 (Key at 3)		2	19	20	2	5	-	780
	Cap goes to top of tube							
31LQ6		4	19	23	2	3	1267	●126780
	●Ignore glow on 1-2. Cap goes to top of tube.							
40KG6*		4	19	20	2	9	123678	680
	Levers #1-2-3 must be thrown to open position							
	Cap goes to top of tube							
	*Must use magnoval adapter							
42EC4*		4	19	22	2	0	278	●278
	●Ignore glow on 2-7. Cap goes to top of tube							
	*Must use magnoval adapter							
50GY7 (Key at 3)	Di	2	20	18	3	7	-	5
(Key at 4)	Pen	3	20	23	2	0	-	12
7751		2	9	22	2	8	14	1345

FOREIGN

E-80CC	Tri-1	9	9	7	1	3	45	12
"	Tri-2	9	9	7	1	8	-	67
	Fil Cont - also throw 4-5 together							
E-235L		2	9	22	2	8	14	1345
E-810F		4	9	19	2	13	1369	2679
EF-804		4	9	23	2	3	26	789
GZ-32	Plate-1	2	8	6	1	-	-	4
"	Plate-2	2	8	6	1	-	-	6

